



# AME 900 F VV

# AIRMASTER



Measures in mm.

2024-10-21

DWG.:1030293

	DK	NO	SV	DE	NL	FR
1	Afkast	Avkast	Avluft	Fortluft	Afvoer lucht	Rejet d'air vicié
2	Indtag	Tilluft	Uteluftintag	Außenluft	Verse lucht	Prise d'air extérieur
3	Indblæsning	Innblåsning	Tilluft	Zuluft	Inblaas	Air soufflé
4	Udsugning	Avtrekk	Frånluft	Abluft	Afzuig	Air repris
5	-	-	-	-	-	-
6	-	-	-	-	-	-
7	El-tilslutning	El-tilkobling	Elektrisk anslutning	Elektrischer Anschluss	Elektrische aansluitingen	Raccordement électrique
8	Vægbeslag	Veggbrakett	Väggfäste	Wandhalterung	Muurbeugel	Support mural

## AIRMASTER

Airmaster A/S  
Industrivej 59  
9600 Aars  
Danmark

Tel.: +45 98 62 48 22  
info@airmaster.dk  
www.airmaster.dk



Helios Ventilateurs  
Le Carré des Aviateurs  
157 av. Charles Floquet  
93155 Le Blanc Mesnil Cedex  
France

Tél. +33 1 48 65 75 61  
Fax. +33 1 48 67 28 53  
info@helios-fr.com  
www.helios-fr.com

Airmaster Norge AS  
Brogata 7  
2000 Lillestrøm  
Norge

Tel. +47 99 08 04 44  
info@airmaster-as.no  
www.airmaster.as.no



SAV Systems  
Scandia House, Boundary Road  
Woking, Surrey  
GU21 5BX  
United Kingdom

Tel: +44 1483 771910  
info@sav-systems.com  
www.sav-systems.com

Airmaster Belgique  
Santvoortbeeklaan 23B  
2100 Deurne  
Belgique

Tel.: +32 (0) 4 70 11 26 33  
info@airmaster.be  
www.airmaster-as.com/fr



Johann Wernig KG  
Unterbergen 40  
9163 Unterbergen im Rosental  
Österreich

Tel. +43 4227 2213-0  
Fax. +43 4227 3564  
office@wernig.at  
www.wernig.at

Airmaster B.V.  
Lage Mosten 49  
4822 NK Breda  
Nederland

Tel.: +31 10 307 06 25  
info@airmaster-bv.nl  
www.airmaster-as.com/nl



WESCO AG  
Tägerhardstrasse 110  
5430 Wettingen  
Schweiz

Tel. +41 56 438 12 12  
Fax. +41 56 438 12 10  
airmaster@wesco.ch  
www.wesco.ch