

Warning and Alarm.
Flashes/constantly yellow for warnings and red for alarms.
See Operator's Manual page 9.

Cancel automatic operating lock.
Press current air flow for at least 1 second.

Set air flow.
Press current air flow and drag with finger to desired air flow.

Holiday Mode Symbol.
Shown when in holiday mode.

Activate Holiday Mode.
Press for min. 2 seconds.

"auto".
Shows when unit is in automatic operation.

Mini-B USB port.
See Operator's Manual page 6.

Function button.

Start or restart automatic operation.
Press.

Deactivate Holiday Mode.
Press

Start operation manual.
Double press.

Standby.
Press if unit is in operation.

Switch off.
Press for min. 2 seconds. Afterwards the unit has to be started by using function button.

Child Lock.
See Operator's Manual page 6.

Warning and Alarm.

Yellow for warnings and red for alarms. See Operator's Manual page 23.

Set air flow.

Press current air flow and drag with finger to desired air flow.
Or
Press direct on the desired air flow.



CO₂ level symbol (shows with active CO₂ sensor).

Press symbol to see current CO₂ level.

Cancel automatic operating lock.

Press padlock and drag in direction of arrow.



"auto".

Shows when unit is in automatic operation.

Mini-B USB port.

See Operator's Manual page 11.

Function button:

Start control menu.

Press.

- Start or restart automatic operation.

Press "⏻ AUTO".

- Start operation manual.

Press "⏻ START".

- Standby.

Press "zzz STANDBY".

- Switch Off.

Press "⏻ OFF". Afterwards the unit has to be started manually.

- Activate Holiday mode.

Press "🏠 HOLIDAY MODE".

- Setup.

Press "⚙️ SETUP". (See Operator's Manual page 16 to 19.)

- Status menus.

Press "📄 STATUS".

- Cancel Screen lock.

See Operator's Manual page 19.

Switch off.

Press for min. 2 seconds. Afterwards the unit has to be started manually.