



Name of component

| | | | | | |
|----|--|-----|-------------------------------|-----|---|
| BP | Bypass (motor driven) | ETV | Exhaust temperature sensor | OTV | Outdoor temperature sensor |
| CH | Comfort Heater (option) | FT | Float | PHS | PreHeating Surface (option) |
| CP | Condensate Pump (option) | F1 | Inlet fan | PI | Airflow-measurement, inlet |
| CT | Condensate Tray | F2 | Extraction fan | RT | Room temperature sensor |
| ED | Exhaust Damper (motor driven, spring return) | HE | Countercurrent Heat Exchanger | SD | Supply Damper (motor driven, spring return) |
| EF | Extraction air filter | IF | Fresh air filter | | |
| | | IT | Inlet temperature sensor | | |