



Name of component

BP	Bypass (motor driven)	ETV	Exhaust Temperature Sensor	IT	Inlet Air Temperature Sensor
CH	Comfort Heating Surface (option)	FT	Float	OTV	Outside Temperature Sensor
CP	Condensate Pump (option)	F1	Supply Air Fan	PE	Flow Meter, extracted air
CT	Condensate Tray	F2	Extract Air Fan	PHS	Preheating Surface (option)
ED	Exhaust Air Damper (motor driven)	HE	Countercurrent Heat Exchanger	PI	Flow Meter, supply air
EF	Extract Air Filter	IF	Supply Air Filter	RT	Room Temperature Sensor
		IG	Inlet Grille (motor driven)	SD	Supply Air Damper (motor driven)